

Generation of Key Dumps for DAS-2A systems (W168 A-Class)

Load the EEPROM dump from the WSP (Immobilizer Box) of W168 A-Class and select which keys you wish to program. You can also drag and drop the dump and it will be opened automatically.

When you are ready, please make sure you have connected the transponder programmer to your AVDI interface. If the transponder is successfully programmed, you will see an information message and you can start the vehicle.

