AUDI BCM2 - MANUAL

Device Functions as follows:

Alarm OFF:

DIP switch: 12345678
DIP switch: xxxx1xxx

Alarm OFF function is set:

- Step1: this step exists only if "Alarm OFF function"
is choosen (DIP switch pozition 5 is "ON")
After ~10 seconds Procedure will finish with device
beep & green led will lit.

KeyLearn:

DIP switch: 12345678
DIP switch: 1x11xxBA
AB: Number Of Keys To Learn:

AB | NumberOfKeysToLearn |
01 | 1 |
10 | 2 |
11 | 3 |
00 | 4 |

KeyLearn procedure:

Plug device to vehicle OBDII connector.
- **Step1:**
Reading data from car:
-After ~10 seconds device will start blinking red/yellow/green.
-Please Unplug & Plug BCM2 power connectors (black & brown).
-Procedure will finish with device beep & green led will lit.

- **Step2 :**
Making Dealer Key:
-Device yellow led will start blinking.
-Please put KeyFob in device coil.
-Procedure will finish with device beep & green led will lit.
-Please remove KeyFob from device coil.

- **Step3 :**
- Learn Key(s) (new dealer key & old keys):
Device green led will start blinking.
- Please plug first key in vehicle key holder for maximum ~10 sec, then unplug.
- Please plug next key in vehicle key holder for maximum ~10 sec, then unplug.
- Please plug last key in vehicle key holder for maximum ~10 sec, then unplug.
- Procedure will finish with device beep and green led will lit.